


SMART TRAVERSE


CONTINUOUS INK JET

OPERATING MANUAL



REVISED:

SEPTEMBER 15, 2011



Servo Driven
Speed > 1000 mm per second
Voltage 120/240 VAC 10A
Print Direction: Left to Right & Right to Left
Weight: Approx 35 lbs. (Actuator Only)
Mounting Hardware: Standard & Custom
 (Stainless Steel) available.
 Flexible Programmability for each application.

**Stainless Steel B2
 Finish**

OPTIONAL HMI

A HMI-Color Touch Screen
 System Programmable
 Can be remotely mounted.

DIMENSIONS	AVAILABLE LENGTHS		
	900MM	700MM	500MM
A	1225MM	1030MM	790MM

DRAWN		QMS, SIOUX FALLS, SD 57105		
CHECKED		TITLE		
QA		CIJ SmartTraverse		
MFG		9000 Series compatible		
APPROVED		SIZE	DWG NO	REV
		C	CIJ Traversing Spec Sheet	
		SCALE	SHEET 1 OF 1	

TRAVERSE SETUP PROCEDURE:

Setting the travel distance of the traverse.


STEP 1: Turn "OFF" power to the traverse system.

STEP 2: Turn "ON" power to the traverse system.

STEP 3: Initiate home sequence and/or allow homing sequence to complete.


IMPORTANT: *The home sequence must be completed before continuing to next step.*

STEP 4: Remove connector on Main Control board at pins 7 & 8 (see photo FIG A).



STEP 5: Set "Auto Run" selector switch to "OFF" position (Down) (see photo FIG B).

STEP 6: Turn "Rotary Speed" selector to position 7 as shown in Photo FIG B.



STEP 7: Move “Print head carriage” to required position.

NOTE: *The travel distance cannot exceed the limit of the “end of travel” sensor.*

STEP 8: Press and Hold the “CYCLE” button on main control board until the COMM LED illuminates.

FIG C




FIG C

NOTE: *If LED does not illuminate, the teach process may not be successful.*

STEP 9: Return “Rotary Speed” selector to original speed setting (0-6).

STEP 10: Position “Auto Run” selector to desired position (on or off).

STEP 11: Replace connector on Main Control board at pins 7 & 8.

IMPORTANT: *Depending on configuration of the “HOME INITIATE” input, motion may commence!*

REFERENCE SENSORS:

Two sensors are located on each end of the traverse actuator. By default, the sensor closest to the servo motor is referred to as the HOME switch and the sensor on the opposite end of the actuator references the end of travel sensor or EOT. The photo FIG A shows the HOME sensor mounted on the actuator. The sensor has an adjustment range of approximately 30mm.



APPROXIMATELY 30mm
ADJUSTMENT RANGE

IMPORTANT:


During NORMAL operation should the axis reach the EOT (End Of Travel) sensor, the system will immediately STOP motion and will automatically call an HOME move. Should this occur the system will need to be adjusted such that the carriage never reaches the EOT sensor. This can be accomplished by either adjusting the EOT sensor or reducing the travel distance of the traverse.

Both the Home and EOT reference sensors are connected in a single harness connected to a bulkhead quick disconnect fitting located on the end of the traverse actuator. See PHOTO FIG B




FIG B

A quick disconnect cable (FIG C) connects to the bulk head fitting located on the traverse actuator.



Connection to the Main Control circuit board are as pictured below.



By default; the home sensor wire is connected to input 7+ and the EOT sensor is connected to input 8+ as pictured above (FIG D).


NOTE: In some instances where the traverse system must home “away” from the servo motor, the connectors can be interchanged to accommodate reverse rotation. The reverse rotation is possible by reversing the timing pulley on the actuator.

RUN MODE

The “Run” mode is a required condition for the normal operation of the traverse system. When NOT in the run mode, the system will ignore any cycle input commands and the system will not send a print signal to the printer.

AUTO RUN MODE SETUP:

The traverse system can be configured to automatically transition to the “RUN” mode at a power up or at a positive transition of the enable circuit. To enable the “Auto RUN” setting, the selector switch located on the Main Control Board must be placed in the “ON” (up) position. .




A customer supplied selector switch or relay (maintained) can be wired to the “RUN MODE” input “2

NOTE: A home sequence must be completed for the system to enter the Run Mode.

TRAVERSE SPEED SETTING:

The speed at which the traverse travels can be adjusted to meet the application requirements. A rotary selector switch has settings available from 0 to 7. Setting number 7 is reserved for programming. Valid settings are 0 through 6. Setting 0 will result in the slowest speed setting and setting 6 will provide the fastest speed setting.



ROTARY SPEED
SELECTOR SWITCH

NOTE: On board versions C and later, there are 2 rotary selector switches available. The switch associated with the speed control is located nearest the AUTORUN selector switch.

System status LED Indicators and Relays:


The three LED indicators located on the Main Control circuit board will show the system status of system. The following is a brief description of how they operate.

READY LED: Steady “ON” indicates the system is “Ready” to operate. The associated relay is typically used to interface between the traverse unit and the customers packaging machine. A solid state relay is provided for isolation of power.


FAULT LED: Steady “ON” indicates the “enable circuit” is open Connector 7 & 8 (either channel) or dip switch settings 7 or 8 are in the “OFF” position.

Flashing Fault LED indicates the printer faults and or warning relays are open. Be sure the printer is not in a “fault or warning” condition.

COMM LED: Indicates the system has not completed a “Home” sequence and the system is not in the “RUN” mode.




IMPORTANT! Do not connect any other devices to the control power of the traverse system other than what is listed on the wiring diagram. Connecting auxiliary devices may cause erratic operation and or severe damage to the traverse system.



PRINTER INTERFACE		
PIN	COLOR	SIGNAL
1	BLACK	DTOP+
2	RED	24 VDC
3	GREEN	INVMS+
4	BROWN	24 VDC
5	BLUE	TACHY +
6	WHITE	TACHY -
7	PINK	FAULT COMMON
8	PURPLE	FAULT NO
9	YELLOW	WARN COMMON
10	GRAY	WARN NO

FEED BACK PCB		
COLOR	PIN	
BLU	1	
BLU/WHT	2	
GRN	3	
GRN/WHT	4	
VIO	5	
ORG & BLK	6	
NC	7	
WHT	8	
NC	9	
VIO/BLK	10	
ORG/WHT	11	
BRN	12	
GRAY	13	
RED	14	
NC	15	



DRAWN Dan Stock		QMS, SIOUX FALLS, SD 57105	
CHECKED		TITLE SmartTraverse	
QA		CIJ - 9000 Series	
MFG		Wiring Diagram	
APPROVED		SIZE D	DWG NO
		SCALE	REV
		SHEET 1 OF 1	

DIAGNOSTIC LED ERROR CODES


WARNINGS

1	Chasis Heatsink Temp Warning	LOWER AMBIENT TEMP
2	Chasis Ambient Temp Warning	LOWER AMBIENT TEMP
4	Motor Calculated Temp Warning	REDUCE DUTY CYCLE
5	Overtravel PLUS Warning	MOVE OFF AXIS
6	Overtravel MINUS Warning	MOVE OFF AXIS

FAULTS


11	Drive Memory Fault	CONTACT QMS
12	Buss Over Voltage	EXCESSIVE AC INPUT VOLTAGE
13	PM Over Current	INTERNAL MOTOR WINDING SHORT CIRCUIT
14	Over Power Fault	CHECK FOR MECHANICAL LOAD PROBLEMS
15	Motor Temperature Fault	CHECK MOTOR WIRING
16	Continuous Current Fault	CHECK FOR MECHANICAL LOAD PROBLEMS
17	Chasis Heatsink Temp Fault	CHECK FOR MECHANICAL LOAD PROBLEMS
22	Feedback Fault	VERIFY ENCODER WIRING IS CORRECT
23	Chasis Ambient Temp Fault	LOWER AMBIENT TEMPERATURE, INCREASE CABINET COOLING
25	Drive Timing Fault	CONTACT QMS
26	Drive Interface Fault	CONTACT QMS
27	User SET Fault	CONTACT QMS
31	F1 Communication Fault	VERIFY ENCODER WIRING IS CORRECT
32	Over Speed Fault	CHECK CABLES

33	Over Current Fault	CHECK FOR MECHANICAL LOAD PROBLEMS
34	Drive Communications Fault	CONTACT QMS
35	Power Module Fault	VERIFY AC INPUT VOLTAGE IS CORRECT
36	Setup Data Fault	INVALID CONFIGURATION DATA
41	Relay Fault	CONTACT QMS
42	PM2 Over Current Fault	REMOVE ALL POWER AND MOTOR CONNECTIONS. PERFORM CONTINUITY CHECK
43	PM Over Temperature Fault	CHECK FOR MECHANICAL LOAD PROBLEMS
44	Motor Ground Fault	MAKE SURE MOTOR GROUND CONNECTIONS ARE CORRECT
45	AC Input Over Voltage	VERIFY INPUT VAC IS WITH SPECIFICATIONS
46	Overtravel PLUS Fault	CONTACT QMS
47	Overtravel MINUS Fault	CONTACT QMS
52	Digital Link Communications Error	CORRUPT DIGITAL LINK MESSAGES RECEIVED
53	Undetermined Drive	DRIVE DAMAGED
77	Drive Not Ready	CONTACT QMS



OPTIONAL
HMI

INDUSTRIAL INTERFACE BOARD



Red
Black
Brown
Green

OPTIONAL MESSAGE LIBRARY
SELECT

SENSOR; End of travel
SENSOR; Home

Mounted on Actuator frame

Home/EOT Cable

White
Brown
Blue
Black

Auto Home Jumper ***

TACHY+
TACHY-

OUT TO PARENT MACHINE
CYCLE START
PRINTER 24VDC
PRINTER FAULT

* Channel 1 Enable Jumper
* Channel 2 Enable Jumper

DRAWN Dan Stock	9/15/2011			
CHECKED		TITLE		
QA				
MFG				
APPROVED				
		SIZE C	DWG NO	REV
		Control Interconnect Board Rev		
		SCALE	SHEET 1 OF 2	